

Installation instructions for the Yepp® Easyfit carrier

The Yepp® Easyfit carrier is suitable for fitting to standard luggage carriers with a load capacity of 25 kg that meet EN 14872.

The Yepp® Easyfit carrier has a special installation frame for the Yepp® Easyfit rear seat as well as to the GMG Classic T30 and 911 seats. The maximum width of the carrier is 17.5 cm.

Installing the Yepp Easyfit carrier

- Position the Yepp® Easyfit carrier on the luggage carrier and insert the 4 bolts from above into the four large slots. See the picture below for the proper positioning (Photo 1)
- Insert the bolts into the 4 clamps positioned under the Yepp® Easyfit carrier. Note the proper position of the clamps (Photo 2).





Photo 1



Photo 2

- Position the Yepp® Easyfit carrier exactly on your luggage carrier and tighten the bolts firmly. Check the bolts after a few weeks and tighten them again if necessary.
- The Yepp® Maxi Easyfit can be quickly and simply fitted after the installation.
- The position depends on the type and size of the cycle, and the centre of gravity of the Yepp® Maxi Easyfit must never be further than 10 cm behind the rear axle (see the user instructions for the Yepp Maxi Easyfit).

Recommendation

After installing and fitting the Yepp® Maxi Easyfit, please check whether the cycle could tip over backwards when the child is in the seat. If so, move the Yepp® Easyfit carrier forwards. Check regularly that all fittings are sufficiently tight.

Warnings

- The Yepp® Easyfit carrier can only be installed on luggage carriers with a load capacity of 25 kg that meet EN 14872.
If the Yepp® Easyfit carrier is used with the Classic junior 911, the luggage carrier must have a load capacity of 35 kg.
- Use the Yepp® Easyfit carrier only on a cycle that is suitable for carrying the additional load. Check the cycle handbook or consult the cycle manufacturer or your dealer.
- The Yepp® Easyfit carrier must not be used on motorised vehicles (including mopeds, scooters, etc.) apart from E-bikes.
- Never modify the carrier yourself.
- Do not use the carrier if any part of it is faulty.

Safety advice

- Use a good two-legged stand.